


Easylogics Apple Corer



Kitchen Preparation

Easylogics Apple Corer

“An apple a day keeps the doctor away!”

- **Easily remove the core of an apple with the Easylogics Apple Corer. Just push, and pull!**
- Perfect for removing the core from apples, pears and tomatoes.
- Also can be used to remove the inside of a cucumber or zucchini before stuffing.
- Always use a Cutting Board to avoid damage to countertop.

Kitchen Preparation



Key Features and Benefits

Kitchen Preparation

Long, strong, sharp and non-rusting blade

Thumb rest for coring

Place thumb on flat area and push when coring out


Hang for storage

Serrated tips to cut through skin and flesh

Ergonomic handle and shape

Short tip for easy removal of core after cutting

Fluted cutting edge for cleaner cut



Size: 20.7 x 3.1 x 2.2 cm high



Use the Apple Corer Vertically

- Place the apple on Cutting Board and hold with one hand. With the other hand, place the round cutting tip around the stalk and push into the apple.
- Once at the bottom, remove the Apple Corer from the apple by pulling it back.
- Discard the core from the Apple Corer by pulling the stalk.



Use the Apple Corer Horizontally



- Take an apple in one hand and with the other hand, place the round cutting tip around the stalk.
- Slide the apple corer into the apple by turning and pushing it slightly until you arrive at the other end.
- Remove the Apple Corer from the apple by pulling it back.
- Discard the core from the Apple Corer by pulling the stalk.

